



WINDOW LATCH / LOCK STANDARDS

THE TYPE, QUANTITY, AND LOCATION OF SASH LATCHES OR LOCKS DEPEND ON TWO FACTORS, SIZE OF SASH AND LOCATION OF WINDOW RELATIVE TO FLOOR. REFER TO THE CHART BELOW FOR A TRADITIONAL PUSH OUT CASEMENT & FRENCH WINDOWS.

UNITS INSTALLED UP TO 18" ABOVE FINISH FLOOR			
SASH HEIGHT	TYPE	QTY.	LOCATION
18" TO 42"	LATCH	1	CENTER
42" TO 84"	LATCH	2	25% TOP & BTM
84" & ABOVE	MULTIPOINT LOCKS	1	24" ABOVE SASH BOTTOM, MIN.

UNITS INSTALLED ABOVE 18" FROM FINISH FLOOR			
SASH HEIGHT	TYPE	QTY.	LOCATION
18" TO 42"	LATCH	1	CENTER
42" TO 60"	LATCH	2	25% TOP & BTM
60" & ABOVE	MULTIPOINT LOCKS	1	24" ABOVE SASH BOTTOM, MIN.